


Carefully remove the café barrier components from the packaging. Place all components on a clean and smooth surface to prevent scratching.

Double check that all components are present.



1.0M/1.5M/2.0M Café Barriers.







## Components


Instructions



#### Pole & Base

**1.** Use the spanner to assemble the base in the order shown below. (L,J,K,H,G,I). Ensure all components are tightly fastened.

2. Screw the side pole into the base until tight as detailed below. When re-tightening please ensure you tighten the base separately before reattaching the post.



#### Banner

1. Insert the Upper Crossbeam into the Upper Pocket and clip into the top bracket on the post, then repeat this for the other side.

**2.** Insert the Lower Crossbeam into the Lower Pocket.

**3.** Attach one end of the Spring Clip to the Lower Crossbeam and the other to the base of the post (as pictured) and repeat for the other side.

# **Safety Instructions**

Please take care when assembling and operating the café barriers. Ensure you are wearing appropriate PPE at all times.

Ensure all bases are level.

**DO NOT** use café barriers in windy conditions.

**DO NOT** position the café barriers on uneven or loose surfaces.

**DO NOT** sit, lean or stand on the café barriers as this may result in injury and/or damage.

### **Care Instructions**

When cleaning your café barrier use a soft damp cloth and a mild detergent.

**DO NOT** use abrasive agents or solvents as they may harm the finish of the café barriers.

During periods of inclement weather the café barriers should be stored indoors.

Fabric banners should be fully dry before storage.



Visit **www.outdoordisplay.co.uk/guidance** for more resources including our assembly video and downloadable signage.